

# LabNotebook

Bijan Varjavand

October 27, 2016

## 1 Introduction

This day our group cold rolled all of our samples. We then took dimensional measurements on our samples.

### 1.1 Goals

The goal was to generate data about the effects of cold rolling on different materials.

## 2 Purpose

Cold rolling is a common materials science processing step, and understanding of it will give students a deeper understanding of the field.

## 3 Setup

The samples were prepared beforehand as rectangular prisms. The entire group took 2 vices and hacksaws to an external shop that had a cold rolling machine.

### 3.1 Materials

1018 Steel annealed, 6061 Al annealed.

### 3.2 Tools

Cold rolling machine, calipers, hacksaw.

## 4 Procedure

We cold rolled our samples to lower and lower thicknesses, cutting a piece of at various thicknesses for analysis. The dimensions of each piece were recorded.

## 5 Results

Each round of rolling was a few rolls, enough to have visual thickness change.

	Al 6061(mm)	Steel 1018(mm)
0 rounds	7.93x25.33	7.9x31.69
1 round	6.14x25.70	6.45x32.17
2 rounds	4.80x26.11	4.76x33.58
3 rounds	2.25x26.20	2.25x36.10
4 rounds	1.10x27.60	1.40x37.50

## 6 Observations

Rolling affected dimensions in the way we expected, but affected each material differently. This is due to the elasticity difference between the two metals.